

## Alphabetical index

## Alphabetical index

<b>A</b>	A/C .....156	Audio system	Antenna .....168
	ABS		Cassette player .....169
	ABS .....140		CD changer .....172
	Warning light .....294		Optimal use .....178
	Adaptive front lighting system		Radio .....165
	AFS.....130		Steering switch .....180
	Warning light.....294		Auto anti-glare mirror .....49
	Air conditioning system		Automatic air conditioning
	Automatic air conditioning		system .....156
	system .....156		Automatic headlight leveling
	Air conditioning filter .....258		system
	Airbags		Automatic headlight leveling
	Airbag operating conditions .....73		system .....131
	Airbag precautions		Warning light .....294
	for your child .....80		Automatic light control
	Airbag warning light .....294		system .....129
	General airbag precautions .....77		Automatic transmission .....116
	Locations of airbags .....71		Auxiliary box .....189
	Modification and disposal	<b>B</b>	
	of airbags .....81	Back-up lights	
	Proper driving posture .....69		Replacing light bulbs .....277
	Side airbag		Wattage .....344
	operating conditions .....73		Battery
	Side airbag precautions .....80		Checking .....237
	Alarm .....66		If the battery is discharged .....317
	AM/FM radio .....165		Preparing and checking
	Antenna .....168		before winter .....149
	Anti-lock brake system		Brake
	Anti-lock brake system .....140		Brake assist system .....140
	Warning light .....294		Fluid .....234
	Ashtrays .....192		Parking brake .....121
			Warning light/buzzer .....292

## Alphabetical index

### C

#### Care

Exterior .....208

Interior .....211

Cargo capacity .....145

Cargo hooks .....198

Cassette player .....169

CD changer .....172

Chains .....150

Charging system warning light .....293

#### Child restraint system

Booster seats, definition .....88

Booster seats, installation .....96

Convertible seats,  
definition .....88

Convertible seats,  
installation .....94

Infant seats, definition .....87

Infant seats, installation .....94

Installing CRS with  
lower anchorages .....92

Installing CRS with seat belts .....94

Installing CRS with  
top straps .....97

#### Child safety

Airbag precautions .....80

Child restraint system .....87

How your child should  
wear the seat belt .....43

Installing child restraints .....91

Power window lock switch .....53

Power window precautions .....55

Removed wireless remote control  
battery precautions .....261

Seat belt extender  
precautions .....46

Seat belt precautions .....44

Seat heater precautions .....195

Trunk .....31

Cigarette lighter .....193

#### Cleaning

Exterior .....208

Interior .....211

Clock .....191

Coin box .....188

Condenser .....234

Console box .....187

Cruise control .....137

Cup holder .....188

Customizable features .....364

<b>D</b>	Daytime running light system .....	130
	Defogger	
	Rear window defogger .....	161
	Dimension .....	336
	Discharge headlights	
	Automatic headlight	
	leveling system .....	131
	Wattage .....	344
	Do-it-yourself maintenance .....	220
	Door courtesy lights	
	Wattage .....	344
	Doors	
	Door courtesy light .....	183
	Door lock .....	22, 25
	Outside rear view mirrors .....	50
	Driver's seat belt reminder	
	light .....	302
	Driving	
	Correct posture .....	69
	Procedures .....	104
	Driving position memory .....	35

<b>E</b>	ECT	
	Pattern select switch .....	117
	Engine	
	Compartment .....	227
	Engine (ignition) switch .....	113
	Hood .....	224
	How to start the engine .....	113
	If your vehicle will not	
	start .....	314
	Engine (ignition) switch .....	113
	Malfunction indicator	
	lamp .....	294
	Engine coolant	
	Capacity .....	340
	Checking .....	232
	Preparing and checking	
	before winter .....	149
	Engine coolant temperature	
	gauge .....	123
	Engine immobilizer system .....	64
	Engine oil	
	Capacity .....	338
	Checking .....	228
	Preparing and checking	
	before winter .....	149
	Event data recorder .....	290

## Alphabetical index

<b>F</b>	First-aid kit space ..... 198	<b>G</b>	Garage door opener ..... 200
	Floor mats ..... 197		Gas station information ..... 388
	Fluid		Gauge and meter ..... 123
	Brake ..... 234		Glove box ..... 186
	Power steering ..... 236	<b>H</b>	Head restraints
	Washer ..... 241		Adjusting ..... 38
	Fog lights		Headlight aim ..... 273
	Switch ..... 132		Headlight cleaner ..... 136
	Wattage ..... 344		Headlights
	Foot lights ..... 183		Switch ..... 129
	Front passenger occupant		Wattage ..... 344
	classification system ..... 82		Heaters
	Front passenger's seat belt		Outside rear view mirror ..... 161
	reminder light ..... 302		Seat heaters ..... 195
	Front seats		Hood ..... 224
	Adjustment ..... 33		
	Fuel		
	Capacity ..... 338		
	Fuel gauge ..... 123		
	Information ..... 345		
	Low fuel level warning light ..... 301		
	Refueling ..... 60		
	Fuel door ..... 60		
	Fuel filler door ..... 60		
	Fuel pump shut off system ..... 289		
	Fuses		
	Blade type ..... 262		
	Cartridge type ..... 271		

<b>I</b>	I/M test ..... 219	<b>K</b>	Key reminder buzzer ..... 28
	Ignition		Keys
	Keys ..... 20		If you lose your keys ..... 316
	Switch ..... 113		Engine (ignition) switch ..... 113
	Engine switch light ..... 183		Key number ..... 20
	In case of an emergency		Keys ..... 20
	If the battery runs out ..... 317		Wireless remote control ..... 22
	If the retractable hardtop	<b>L</b>	Light bulbs
	does not close ..... 323		Replacing ..... 276
	If the shift lever cannot be		Wattage ..... 344
	shifted from P ..... 315		Lights
	If you have a flat tire ..... 303, 305		Fog lights switch ..... 132
	If you lose your keys ..... 316		Headlights switch ..... 129
	If you think something is		Interior light switch ..... 184
	wrong ..... 288		Personal light switch ..... 184
	If your vehicle becomes		Replacing light bulbs ..... 276
	stuck ..... 322		Turn signal lever ..... 120
	If your vehicle needs to		Vanity lights ..... 190
	be towed ..... 283		Wattage ..... 344
	If your vehicle overheats ..... 320		Load limits ..... 148
	If your vehicle will not start ..... 314		Low engine oil level warning
	Indicator lights ..... 125		light ..... 301
	Initializing your Lexus ..... 367		Low engine oil pressure warning
	Inside rear view mirror ..... 49		light ..... 293
	Interior light ..... 184		Low fuel level warning light ..... 301
<b>J</b>	Jack		Low washer fluid warning light ..... 301
	Positioning a floor jack ..... 225		Luggage cover ..... 199
	Vehicle-equipped jack ..... 305		
	Jack handle ..... 305		
	Jump starting ..... 317		

## Alphabetical index

<p><b>M</b> Maintenance</p> <ul style="list-style-type: none"> <li>Do-it-yourself maintenance .....220</li> <li>General maintenance .....216</li> <li>Maintenance data .....336</li> <li>Maintenance requirements .....214</li> </ul> <p><b>Meter</b></p> <ul style="list-style-type: none"> <li>Instrument panel light control .....124</li> </ul> <p><b>Meters</b> .....123</p> <p><b>Mirrors</b></p> <ul style="list-style-type: none"> <li>Auto anti-glare mirror .....49</li> <li>Outside rear view mirror heaters .....161</li> <li>Outside rear view mirrors .....50</li> <li>Vanity mirrors .....190</li> </ul> <p><b>N</b> Noise from under vehicle .....14</p> <p><b>O</b> Odometer .....123</p> <p><b>Oil</b></p> <ul style="list-style-type: none"> <li>Engine oil .....228</li> </ul> <p><b>Open door warning light/buzzer</b> .....301</p> <p><b>Opener</b></p> <ul style="list-style-type: none"> <li>Fuel filler door .....60</li> <li>Hood .....224</li> <li>Trunk .....29</li> </ul> <p><b>Outer foot lights</b></p> <ul style="list-style-type: none"> <li>Outer foot lights.....183</li> <li>Wattage.....344</li> </ul> <p><b>Outside rear view mirrors</b></p> <ul style="list-style-type: none"> <li>Adjusting and folding .....50</li> <li>Driving position memory .....35</li> </ul>	<p><b>P</b> Parking brake .....121</p> <p><b>Parking lights</b></p> <ul style="list-style-type: none"> <li>Switch .....129</li> <li>Wattage .....344</li> </ul> <p><b>Personal lights</b></p> <ul style="list-style-type: none"> <li>Switch .....184</li> <li>Wattage .....344</li> </ul> <p><b>Power outlet</b> .....194</p> <p><b>Power steering fluid</b> .....236</p> <p><b>Power windows</b> .....53</p> <p><b>R</b> Radiator .....234</p> <p>Radio .....165</p> <p>RDS .....166</p> <p>Rear seat belt holder .....42</p> <p>Rear window defogger .....161</p> <p><b>Replacing</b></p> <ul style="list-style-type: none"> <li>Air conditioning filter .....258</li> <li>Blade type fuses .....262</li> <li>Cartridge type fuses .....271</li> <li>Light bulbs .....275</li> <li>Wireless remote control battery .....260</li> </ul> <p><b>Retractable hardtop</b> .....56</p> <p><b>Run-flat tires</b> .....303</p>
--	--

<b>S</b>	<b>Seat belts</b>	
	Adjusting the seat belt .....	40
	Automatic Locking Retractor (ALR) .....	42
	Child restraint system installation .....	91
	Cleaning .....	212
	Emergency Locking Retractor (ELR) .....	42
	How to wear your seat belt .....	40
	How your child should wear the seat belt .....	40
	Pregnant women, proper seat belt use .....	43
	Reminder light .....	302
	Seat belt extenders .....	44
	Seat belt guide .....	41
	Seat belt pretensioners .....	41
	<b>Seat heaters</b> .....	195
	<b>Seats</b>	
	Cleaning .....	211
	Child seats/child restraint system installation .....	91
	Driver's seat position memory .....	35
	Head restraint .....	38
	Properly sitting in the seat .....	69
	Seat adjustment .....	33
	Adjustment precautions .....	34
	Seat heaters .....	195
	<b>Service reminder indicators</b> .....	125
	<b>Shift lever</b>	
	Automatic transmission .....	116
	If the shift lever cannot be shifted from P .....	315
	<b>Shift lock system</b> .....	315
	<b>Side airbags</b> .....	71
	<b>Side marker lights</b>	
	Switch .....	129
	Wattage .....	344
	<b>Side mirror</b>	
	Adjusting and folding .....	50
	Mirror position memory .....	35
	<b>Snow tire</b> .....	247
	<b>Spare tire</b>	
	Inflation pressure .....	343
	Storage location .....	306
	<b>Spark plug</b> .....	340
	<b>Specifications</b> .....	336
	<b>Speedometer</b> .....	123
	<b>SRS airbag</b>	
	SRS airbags .....	71
	Warning light .....	294
	<b>Steering wheel</b>	
	Adjusting .....	47
	Audio switches .....	180
	Steering wheel memory .....	35
	<b>Stuck</b>	
	If your vehicle becomes stuck .....	322
	<b>Sub key</b> .....	20
	<b>Sun visors</b> .....	190

## Alphabetical index

### Switch

ECT pattern select .....	117
Engine (ignition) switch .....	113
Fog light switch .....	132
Light switches .....	129
Power door lock switch .....	25
Power window switch .....	53
Window lock switch .....	53

### **T** Tachometer ..... 123

#### Tail lights

Switch .....	129
--------------	-----

#### Talk switch\*

#### Telephone switch\*

#### Theft deterrent system

Alarm .....	66
Engine immobilizer system .....	64

#### Theft prevention labels ..... 68

#### Tire inflation pressure ..... 251

#### Tire pressure warning light ..... 295

#### Tires

Chains .....	150
Checking .....	242
If you have a flat tire .....	303, 305
Inflation pressure .....	251
Information .....	349
Replacing .....	307
Rotating tires .....	242
Size .....	343
Snow tires .....	247

#### Tools ..... 305

#### Total load capacity ..... 148

### Towing

Dinghy towing .....	154
Emergency towing .....	283
Trailer towing .....	153

#### TRAC (traction control)

Traction control .....	140
------------------------	-----

#### Trip information display ..... 128

#### Trip meter ..... 123

#### Trunk

Opener .....	29
--------------	----

#### Trunk light

Wattage .....	344
---------------	-----

#### Turn signal lights

Replacing light bulbs .....	276
Switch .....	120
Wattage .....	344

### **V** Vanity lights

Vanity lights .....	190
Wattage .....	344

#### Vanity mirrors ..... 190

#### Vehicle identification number ..... 336

#### Vehicle load capacity ..... 148

#### VSC (vehicle stability control)

Vehicle stability control .....	140
Warning light .....	295

### **W** Warning buzzers

Brake system .....	292
Key reminder .....	28
Open door .....	302
Retractable hardtop.....	302
Shift range down .....	118

\*: Refer to the "Navigation System Owner's Manual".



**Warning lights**

ABS .....	294
Adaptive front lighting system ....	294
Brake system .....	292
Charging system .....	293
Engine oil level .....	301
Engine oil pressure .....	293
Engine oil replacement .....	301
Low fuel level .....	301
Low washer fluid .....	301
Malfunction indicator lamp .....	294
Open door .....	301
Pretensioners .....	294
Rear light failure .....	295
Seat belt reminder	
light .....	302
SRS airbags .....	294
Tire pressure .....	295
VSC .....	295

**Washer**

Adding .....	241
Low washer fluid warning	
light .....	301
Preparing and checking	
before winter .....	149
Switch .....	133

**Washing and waxing .....** 208

**Weight**

Cargo capacity .....	145
Load limits .....	148
Weight .....	336

**Wheels .....** 256

**Window glasses .....** 53

**Window lock switch**

(power window) .....	53
----------------------	----

**Windows**

Power windows .....	53
Rear window defogger .....	161
Washer .....	133

**Windshield wipers .....** 133

**Winter driving tips.....** 149

**Wireless remote control key**

Replacing the battery .....	260
Wireless remote control .....	22